



Take out pre-assembled cabinet box.



Insert dowels to the frame.



Attach frame to the cabinet box.



Fasten the cam lock from outside of the cabinet box.



Align door to drawer face.



Use nail gun to attach door securely (optional).





Drill holes on drawer face before use screws to prevent cracking.



Six holes for the bottom part, two holes for the top part.



Fasten the drawer front and door with screws.





Now it's finished.