



**Take out one side panel.**



**Attach cam-lock screws into pre-drilled holes.**



**Install drawer track brackets to the back panel.**



**Attach cam-lock screws into pre-drilled holes.**



**Attach two panels together.**



**Use cam-locks on the back panel to make them tight and secured.**



**Attach bottom board with the same process.**



**Attach the other side board with the same process.**





**Fasten and secure all the cam-locks.**





**Attach cam-lock screws to pre-drilled holes on the kick board.**



**Attach and fasten the kick board to the bottom of the cabinet.**



**Attach cam-lock screws to pre-drilled holes on the frame.**



**Attach frame to cabinet body.**



**Fasten and secure all the cam-locks.**







**Install drawer track to the bracket.**







**Secure the front with screws to the frame.**



**Hammered the dove-tailed drawers; use nail gun to give extra strength.**



**Slide in bottom drawer panel.**



**Attach back drawer panel and secure it.**



**Install corner brackets to the bottom of the drawer.**







**Attach to the drawer track.**





**Repeat the same process for the other two drawers.**



**Now it's finished.**