



Take out the door and frame.



Insert the cam-lock screws to the pre-drilled holes on the frame.



Insert the cam-lock screws to the front side panels.



Insert cam-lock screws to the back side panels.



Attach top panel to the back side panel with cam-lock screws.



Attach bottom panel to the back side panel with cam-lock screws.



Fasten the cam-locks on the back of the back panel.



Attach the other back side panel.



Fasten the cam-lock screw.



Attach front side panel.



Fasten the cam-lock screws.





Attach the other front side panel.



Fasten the cam-lock screws.



Slide the back panel in the slot.





Fasten the back panel to top and bottom panel with extra screws.



Attach frame to the box.





Tighten the cam-locks on the front side panels.



Install rubber strip to secure the center panel on the door.



Now it's finished.