



**Insert cam-lock screws into the holes on the side panel.**



**Insert cam-lock screws into the holes on the frame.**



**Attach back panel to side panel.**



**Tighten the cam-locks on the back panel.**



**Attach the other side panel.**



**Attach bottom panel.**



**Attach top panel.**



**Attach frame to cabinet box.**





**Attach shelf pins to the box.**



**Tighten cam-lock screws.**



**Attach door and door frame to the cabinet body.**





**Now it's finished.**